

Sparks Racing Air Filter Maintenance

- ❑ After removing your dirty filter thoroughly clean the air box and air boot. Dirt is your motors number one enemy.
- ❑ It is important to clean and oil the filter whenever it gets dirty.
- ❑ To clean it, we recommend using filter cleaner like Twin Air. Other options would be kerosene or mineral spirits and then a good degreaser like Simple Green, 409, or even a good dishwashing soap.
- ❑ **DO NOT** use gasoline to clean your filter. It can significantly shorten the life of the foam and loosen the glue.
- ❑ The goal is to get all of the old oil and dirt out of the filter. Rinse well and dry before reapplying the oil.
- ❑ Oil your clean air filter with a good pour on type oil, we recommend Twin Air.
- ❑ Pour a liberal amount of oil all over the foam and massage the oil into the filter and squeeze out any extra oil.
- ❑ Reinstall the air filter as per installation instructions.